

myTorch RC 3AAA

Learn more on www.nextorch.com

请登陆:www.nextorch.com 获取更详尽的产品咨讯。

Weight

Congratulations on purchasing our NEXTORCH™ flashlight. You have chosen a high quality product designed from the latest technology. For the best use of this product, please read the instruction manual carefully,

	SPECIFICATION
Bu l b	CREE® R5 LED
Battery	3*AAA batteries(Ni-MH battery or Alkaline battery) Package Induded: Three Japan made FDK® 1.2V AAA Ni-MH rechargeable battery
Output	210 Lumens 2 Lumens
Run Time	70 mins 55 hrs
Beam Distance	166m / 544.48'
Waterproof	IPX-7, 1m / 3.28'
Impact Resistant	1m / 3.28'
Body Material	Aerospace grade aluminum 6061-T6
	with hard-anodized finish
Lens Material	Anti-scratch Polycarbonate
Dimensions	Length:148mm / 5.83"

FEATURES

Body Diameter: 27.6mm / 1.09" Head diameter: 36.0mm / 1.42"

4.76oz / 136 g (With no battery)

- Cree[®] s single R5 LED emitter regulated to maximize output and runtime, with a lifespan of 100,000 hours, to produce -210 lumens on-max-output -- - -
- Multi-charging design: Recharge it with a direct plug-in USB cable into computer, wall charger or in-car charger.
- Built in two Japan made FDK® Ni-MH rechargeable batteries with over-charging and over-discharging protective circuit.
- 4 pre-set modes (High/Medium/Low/Strobe) for the most common lighting applications.
- Smart Torch Technology(STT) implemented for infinite mode setting options.
- Reverse polarity protection, to protect from improper battery installation for user's safety and heavy use.
- Solid heavy-duty aerospace 6061-T6 grade anti-abrasive aluminum body with hard-anodized finish.
- IPX-7 water-proof standard of up to 1 meters / 3.28 feet.
- Shock-proof standard of up to 1meters / 3.28 feet.
- Patented anti-rolling and anti-shock functionality.

QUICK START GUIDE

BATTERY INSTALLATION

- 1. Unscrew the tailcap of the flashlight and remove:
- 2. Insert new battery with positive (+) terminals oriented forward. (Remove old battery and dispose of properly)
- 3. Screw the tailcap back on, press pushbutton to test, NOTE: never mix old and new batteries: always replace all



ON/OFF

Press or click push-button tailcap switch to turn the flashlight

尊敬的用户, 恭喜您拥有了纳丽德手电。它选用最好的材料, 经科学的设计、精密的制造工艺、呈现在您的面前、为了您能 对我们的产品有全面的了解,请仔细阅读我们为您准备的 《使田说阳书》

参数	
灯泡	CREE® R5 LED
电源	可使用2节AA镍氢充电电池或3节AAA碱性电池 厂家标配:3节日本原装进口1.2V AAA镍氢 充电电池
亮度	210流明 — 2流明
续航时间	70分钟 — 55小时
照射距离	
防水等级	IPX-7, 1米
抗摔高度	1米
筒身材料	航天等级强化铝材6061-T6 经II型硬质阳极氧化表面处理
镜片材料	镀增透膜强化PC镜片
尺寸	长度:148毫米 ; 简身直径:27.6毫米 ; 灯头直径:36.0毫米
重量	136克 (不含电池)

产品特占

- 采用美国进口顶级LED,寿命长达10万小时,手电最高亮度 **达210**流明
- 手电多样化充电设计:可通过USB数据线连接电脑、座充、 车充直接对手电进行充电
- 预设四种模式(高-中-低-爆闪),满足多种场合照明需求
- 内置开放式可编程智能控制芯片,可连接电脑个性化设定手 电的亮度、频闪及信号模式,专为每个人量身定做
- 内置日本原装进口FDK®镍氢充电电池,反复充电,节能环保
- 采用电池防反接电路设计,确保手电使用的安全
- 筒身采用航天等级铝材经硬质阳极氧化处理,筒头采用黄铜 镀铬金属压圈,坚固耐用
- IPX-7防水等级,水下1米防水
- 专利防滚动、抗震设计

快速入门

- 电池安装
- 1. 拧开手电尾盖, 并取出手电电池仓
- 2. 将AA电池置于筒身中(注意正确放置电池的正负极); 3. 将尾盖拧回筒身。按下尾部按钮开关,测试手电。
- 注章:更换电池时,请不要将新旧电池混合使用。




● 打开/关闭

Momentary ON/OFF: Lightly press the push-button switch and hold for momentary ON; release the push-button to turn it OFF



Constant ON/OFF: Click the push-button switch all the way in and release it for Constant ON; repeat it to turn it OFF -"Clicking Switch".



Mode Switch

While Operating the "Silent Switch" Repeat pressing and releasing the switch, mode changes according to the following cycle.




While Operating the "Clicking Switch":

Repeat clicking the switch, mode changes according to the same above cycle.

HOW TO CHARGE

To charge the myTorch RC 3AAA (Battery Model # AAA Ni-MH rechargeable battery): Via a USB Port of a computer, wall charger or in-car charger



- 1. Unscrew the head clockwise to reveal the charging USB
- 2. Connect the flashlight and charger via USB cable.
- 3. Turn on the flashlight, to keep the flashlight in working condition.
- 4. When the light indicator appears:
- 1) Green-light Blinking :CHARGING IN PROGERESS
- 2) GREE-light Constant on: FULLY CHARGED
- 3) OFF: CONNECTION NOT MADE
- * myTorch RC 3AAA (FDK® AAA Ni-MH battery) Charging Time: 3 hours 40 minutes charged by USB port of a computer

NOTICE

- 1. Do not shine directly into eyes as the powerful light could cause a permanent injury.
- 2. Do not dismantle the bulb assembly.

MAINTENANCE

- To keep your flashlight in perfect working condition, follow the instructions below.
- (1) Clean your flashlight with a soft clean cloth.
- (2) Wash the flashlight with fresh water after using in the seawater or causticity liquid, and dry it with warm air
- (3) When the tail cap does not rotate smoothly, apply silicone grease on the "O"ring (You can buy the
- silicon grease in outdoor or hardware shops.)
- (4) Please remove the battery and keep them dry and cool when they are not in use for a extended period of time.

ACCESSORIES

NEXTORCH_{TM} offers a full range of product accessories suited for your flashlight. Learn more on www.nextorch.com. Compatible accessories for myTorch RC 3AAA: SL6, LC6, LR03, DC1, G46-A, V1, LT2113, RM25, RM8,

RM81, RM82, RM84

LIMITED LIFETIME WARRANTY

- 1. NEXTORCHTM warrants that this product is free from manufacturing defects.
- NEXTORCHTM will repair or replace any defective flashlight, please contact your local dealer or send an email to info@nextorch.com.
- 2. The consumer will not have coverage or reimbursement under this warranty if the product has been subjected to abnormal use, unauthorized modifications or unauthorized repair.
- 3. Rechargeable batteries will be under warranty within one year from the date of purchase.
- 4. All of the original accessories that are delivered with this product (rechargeable batteries excluded) are not covered under this warranty.

轻按尾部按钮开关 (开关未发出响声) , 即可瞬时点亮手电; 松开手指,则关闭手电。




常亮:按下尾部按钮开关至发出响声,松开手指,打开手电 (手电处于常亮状态);再次重按尾部按钮开关,则关闭手电。



- 1. 重复轻按尾部按钮开关 (未发出响声), 可切换不同的模式。 模式切换顺序:高亮—》中亮—》低亮—》爆闪

2. 重复按下尾部按钮开关(发出响声),可切换不同的模式。 模式切换顺序如上所示。

myTorch RC 3AAA(电池类型:镍氢充电电池)采用多样化充电 方式设计:可通过USB数据线连接电脑、座充、车充、移动电 池包等设备直接充电。



- 1 顺时针方向旋转手由斗部 拧开斗盖至USB充由接口露出
- Z. 通过USB数据连接线,将手电与充电设备(电脑、车充、座 充、 电池包等) 相连接

3. 打开手电尾部按钮开关,使手电充电电流保持导通状态。

- 4. 当充电指示灯显示:
- 1)绿灯闪烁:表示正在充电中
- 2)绿色常亮:表示电池电量已满,充电完毕
- 3) 灯不亮:表示连接未成功
- * myTorch RC 3AAA (FDK® 镍氢电池) 充电时间为:电脑USB 直充3小时40分钟

myTorch RC 3AAA 安全使用指南

- 1. 请不要将光线直射入人的眼睛,较强的光线会对眼睛造成 永久性伤害。
- 2. 请不要拆解灯头,以免造成反光杯或灯泡损伤

myTorch RC 3AAA 保养注意事项

- 每次使用后,请遵循以下几点对电筒进行必要的保养,使其 能继续为您提供高质量的服务。
- (1) 每次使用后,请用干净的软布对电筒进行擦拭。
- (2) 当电筒在沾染海水或腐蚀性液体时,请及时用清水清洗, 并用电吹风吹干。(您可以到专业的户外店、五金店购 买到此类产品,或使用由纳丽德为您准备的专业硅脂, 请参考后面的附件说明。
- (3) 当灯头及尾盖拧动不畅时,请在接口处涂少许硅脂。
- (4) 电筒在不使用时,请将电池取出,放在阴凉处保存。

附件支持

为了满足您对电筒的不同需求,并使电筒得到全面的维护, 我们设计了一系列的配件。请根据您的个人需要进行选择, 如需详细了解附件参数,请登陆网站www.nextorch.com. mvTorch RC 3AAA可用配件: SL6, LC6, LR03, DC1, G46-A, V1, LT2113, RM25, RM8, RM81, RM82, RM84

纳丽德终身保修条款

- 1. 纳丽德承诺: 因产品本身出现的质量问题及缺陷。纳丽德 将提供终身免费保修服务或更换服务。
- 2. 因使用不当或擅自改装、维修而引起的产品缺陷、损坏。 不在终身保修范围之内.
- 3. 充电电池保修期限为自购买日起—年之内。
- 4. 所有随产品附带的配件(充电电池除外),不在保修范围

称: myTorch RC 3AAA说明书 软

件: Illustrator 15 色:K 分辨率: 300 dpi

成品尺寸: 110mmX53mm 展开尺寸: 110mmX477mm

印刷说明:105克铜版纸单色双面印刷 刀膜说明

折叠线

是否转曲:已转曲线